











EPB11 APPLICATION STRUCTURES										
Structure	Location	Co-ordinates	Invert level (m)	Design Footway	Existing Ground	Depth	Headwal l type	Pipe dia (mm)	Overall Ditch width (m)	Construction Notes
3	HEADWALL S61	E421966 N330505	51.930	N/A	52.560	0.735	A	300	N/A	OUTFALL TO WATERCOURSE
4	HEADWALL S90	E422044 N330288	51.800	N/A	52.480	0.755	A	300	N/A	OUTFALL TO WATERCOURSE

Method statement notes

Standard method statement for a 450mm max in underside flow base supported

1. All works to be supervised by competent and trained individual (typically SSSTS or SMSTS certified) - It is supervisors responsibility to brief and ensure permits are in place
2. Work area should be prepared so works can be undertaken with no obstructions
3. Area marked out by competent person and defined fencing placed encompassing the works (pedestrian type barrier up to 1m excavation depth, double clipped heras thereafter)
4. Over pumping pipe work to be installed and laid to agreed area (fenced off where possible to minimise risk of slips and trips) - Pipework should not encroach on pedestrian footpaths/vehicle haul routes
5. Sump to be installed and pumping to commence. Generators to be stored 10m from existing watercourse and should be positioned on a drip tray - All refueling carried out 10m away from watercourse
6. Spills kits should be readily available
7. Establish the area for excavation via paint or wooden pegs - Competent and trained person to scan area for utilities and follow contractors permit to dig procedures
8. Assuming it is safe to break ground, using a 360 excavator carry out the excavation (culvert/new ditch/reshaping of existing ditch profile) whilst a competent banksman is present
9. Excavation arisings to be cleared via forward tipping dumper
10. Form concrete bed for culvert and headwall to sit on

11. Be aware of risk of unsupported trenches, contractor and site teams to confirm particular requirements. Alternatively if there is adequate working space, step the excavation 45° using 1m steps
12. Any pipe culverts required should be placed close to the zone of work prior to work by the contractor/delivery company - Falls from height to be considered during unloading
13. Lift culverts into place using Excavator (associated lifting equipment to be inspected by competent person and appropriate for the operations carried out by competent slinger/signaler Any operatives not required during the lift should vacate the area
14. Paving slabs placed as per arrangement shown
15. Fill the inside of the culvert to false bed level stipulated on this drawing
16. Brick headwall to be constructed
17. Back/B headwall and culvert - Ensure no debris is left in work area prior to removing over-pumping facility

rev	description	date	initial
C	Updates following EA Comments	02/09/22	CJO
B	Updates following EA Comments	17/08/22	CJO
A	Updates following site meeting	12/08/22	CJO

Stephen Daykin Consulting Ltd
A design consultancy for the development industry
31A Longacre
Bingham
Nottinghamshire
NG13 8AF
Tel 01949 838831
mobile 07968 765381
steve@sdccivils.com
Managing Director
Stephen W Daykin I.Eng MICE MCIHT

client
Bellway

project
Proposed residential development at
Derby Road Hatton

title
OUTFALL HEADWALL DETAILS (SHEET 2)

drawn	CJO	date	
scale	AS SHOWN	size	A1

purpose of issue

dwg no.	rev.
E795-50	C